

oatey 42099 shower drain installation instructions

Oatey 42099 shower drain installation instructions are crucial for ensuring a proper and leak-free installation of your shower drain system. Properly installing a shower drain is an essential step in any bathroom renovation or new construction project. The Oatey 42099 model is specifically designed for durability and efficiency, making it a popular choice among homeowners and professionals alike. This article provides a comprehensive step-by-step guide to the installation process, along with tips and best practices to ensure a successful outcome.

Understanding the Oatey 42099 Shower Drain

The Oatey 42099 shower drain is a versatile and reliable solution for managing water drainage in your shower. It is made from high-quality materials, ensuring longevity and resistance to corrosion. The drain features a strainer that prevents debris from clogging your plumbing system, while also allowing for easy cleaning.

Key Features

- Durable Construction: Made from robust materials that withstand regular wear and tear.
- Versatile Design: Suitable for various shower applications, including tile and acrylic.
- Easy Maintenance: Removable strainer for straightforward cleaning and upkeep.
- Adjustable Height: Accommodates different thicknesses of flooring materials.

Tools and Materials Needed

Before you begin the installation process, gather the necessary tools and materials. Here's a list to help you get organized:

- Tools:
 1. Measuring tape
 2. Level
 3. Hammer
 4. Drill and drill bits
 5. Screwdriver
 6. Utility knife
 7. Pipe cutter
 8. Trowel
 9. Safety glasses
 10. Gloves
- Materials:

1. Oatey 42099 shower drain kit
2. PVC or ABS drain pipe (depending on your plumbing system)
3. Silicone sealant or plumber's putty
4. Thin-set mortar or concrete mix
5. Tile (if applicable)

Preparation for Installation

Proper preparation is key to a successful shower drain installation. Follow these steps to ensure everything is set up correctly.

1. Plan the Drain Location

- Determine the optimal location for your shower drain. It should be positioned at the lowest point of the shower floor to facilitate proper water drainage.
- Ensure that the drain is accessible for maintenance and cleaning.

2. Check Plumbing Compatibility

- Verify that your existing plumbing system is compatible with the Oatey 42099 shower drain.
- Check the size of the drain pipe (typically 2 inches) and ensure that it matches the fittings included in the drain kit.

3. Prepare the Shower Floor

- If you are installing the drain in a new shower, prepare the substrate by ensuring it is level and clean.
- For a remodel, remove the old drain and clean the area thoroughly.

Installation Steps

With your tools and materials ready, it's time to install the Oatey 42099 shower drain. Follow these step-by-step instructions for a seamless installation.

Step 1: Cut the Drain Pipe

- Measure the height from the subfloor to the desired height of the shower drain.
- Using a pipe cutter, cut the drain pipe to the required length. Ensure that the cut is clean

and straight.

Step 2: Install the Drain Body

1. Insert the drain body into the cut end of the drain pipe.
2. If necessary, apply PVC or ABS cement to secure the connection.
3. Ensure that the drain body is level and positioned correctly.

Step 3: Secure the Drain Flange

- Place the drain flange on top of the drain body.
- Use screws to securely attach the flange to the drain body, making sure it is flush with the shower floor.

Step 4: Apply Sealant

- Apply a bead of silicone sealant or plumber's putty around the edge of the drain flange.
- This will create a waterproof seal and prevent any leaks.

Step 5: Install the Shower Pan

- If using a pre-formed shower pan, ensure it fits snugly around the drain. Follow the manufacturer's instructions for installation.
- For a custom shower pan, mix thin-set mortar or concrete and fill in the area around the drain. Slope the mortar towards the drain to facilitate proper drainage.

Step 6: Tile the Shower Floor (if applicable)

- If you are installing tile, begin laying your tiles from the drain outward.
- Use a tile spacer to ensure even spacing between tiles.
- Once the tiles are set, allow them to cure according to the manufacturer's instructions.

Step 7: Install the Strainer Cover

- Once the mortar or thin-set has fully cured, place the strainer cover on the drain.
- Ensure it sits flush and is securely in place.

Post-Installation Tips

After the Oatey 42099 shower drain installation, follow these tips to ensure everything functions correctly.

1. Perform a Leak Test

- Before closing up the shower area, perform a leak test by running water through the drain.
- Check for any signs of leaks around the drain area and ensure that water flows freely.

2. Regular Maintenance

- Clean the strainer regularly to prevent clogs and maintain proper drainage.
- Inspect the drain periodically for any signs of wear or damage.

3. Consider Professional Help

- If you are unsure about any part of the installation process, consider hiring a professional plumber to ensure everything is installed correctly.

Conclusion

The Oatey 42099 shower drain installation instructions provide a clear and comprehensive guide to installing a reliable and efficient drainage system in your shower. By following the steps outlined above, you can ensure a successful installation that will provide you with years of trouble-free use. Remember that preparation, attention to detail, and regular maintenance are key to a long-lasting shower drain system. Whether you're a DIY enthusiast or a seasoned professional, the Oatey 42099 model is an excellent choice for your shower drainage needs.

Frequently Asked Questions

What tools are needed for installing the Oatey 42099 shower drain?

You'll need a utility knife, screwdriver, level, measuring tape, and a PVC pipe cutter for the installation of the Oatey 42099 shower drain.

How do I prepare the subfloor before installing the Oatey 42099 shower drain?

Ensure the subfloor is clean, level, and free from any debris. You may also need to create a slight slope towards the drain for proper water flow.

What type of adhesive should I use with the Oatey 42099 shower drain?

Use a PVC solvent cement that is compatible with both the drain and the pipe material for a secure bond during installation.

Can the Oatey 42099 shower drain be used with any shower base?

Yes, the Oatey 42099 shower drain is designed to work with various shower bases, but always check compatibility with your specific base model before installation.

What is the recommended height for the Oatey 42099 shower drain installation?

The drain should typically be installed at a height that allows for a minimum of 1/4 inch per foot slope towards the drain, ensuring proper drainage.

Is there a specific installation sequence for the Oatey 42099 shower drain?

Yes, first, dry fit the drain and the pipes, then secure the drain to the subfloor, connect the drain to the plumbing, and finally apply the adhesive as per the instructions.

Where can I find the installation instructions for the Oatey 42099 shower drain?

The installation instructions can usually be found on the product packaging, or you can download a PDF version from the Oatey website under the support section.

[Oatey 42099 Shower Drain Installation Instructions](#)

Oatey 42099 Shower Drain Installation Instructions

Related Articles

- [only the good spy young](#)

- [ny state real estate exam](#)
- [nuwave pro induction cooktop instruction manual](#)

[Back to Home](#)